

Firmware Update:

Select this option to apply the new firmware. When you find the new firmware, please check the “**System Info**” for current firmware version to see if the device needs to upgrade. If so, please download the firmware file for upgrade. The upgrade procedure is below.

1. Prepare an empty flash disk. Plug it into PC and copy all firmware files to its root directory.
2. Plug it into this device.
3. Open the “Firmware Update” option in the configure menu. Press it and select “OK” to continue.
4. Wait for 5 minutes. Do not unplug the power during the upgrade procedure. When the upgrade is completed, it will reboot and return to the main screen.

